



F161



F16.2



F16.3

400 L 401 402 421 05 422 424 FORMATTER CPU BUFFER 423 SPEECH TRANSLATION 1 1 410 <u>T</u> 1 405 403 407 DISPLAY STORAGE CAMERA I/O ADAPTER ADAPTER ADAPTER 404 406 408 PRINTER KYBD/PNTR ADAPTER NETWORK ADAPTER INTERFACE 411 414 100 412 413

F1G. 4

₹

